








Zeparo ZTD / ZTM / ZTMI / ZHU-ZTD(M) INSTALL







5




6






8


①




②




ZTM




ZTMI




ZTD + ZHU




③




④




⑤




⑥




⑦




⑧






⑨



⑩



9




10




every
5 years



shut off



< 50 °C



① www.imi-hydraulic.com

IMI
Hydronic Engineering

We reserve the right to introduce technical alterations without previous notice.

IMI Hydronic Engineering AG • Mühlerainstrasse 26 • CH-4414 Füllinsdorf • Tel. +41 (0)61 906 26 26
www.imi-hydraulic.com